

## KITCHEN PULLOUT INSTALLATION DEMO:

AMERICAN BRASS #: SL1000-A / SL1000N-A / SL1000ORB-A

- 1.) Align middle spout copper spout valve & white “male” connector flush:



- 2.) Apply gentle pressure (DO NOT JAM) and push white “male” connector up to seal 2-O’rings inside:



- 3.) Continue to apply pressure to white “male” connector until top black o’ring is flush inside body. Slide top “female” connector down while continue to apply pressure to bottom “male” connector:



- 4.) Slowly tighten top “female” connector to bottom “male” connector. Ensure continued pressure is applied to “male” connector to avoid “stripping” of the threads.

